

AIWA

SERVICE MANUAL

TIP

Model / Sasiu

AIWA

AIWA

AIWA

TV 2102

TV 2002

TV 1402


SCHEMATIC DIAGRAM TV-2102, TV-2002, TV-1402 aiwa

S1

S2

S3


S4




NOTE 1 : CIRCUIT CONSTANTS AND CIRCUIT ITSELF ARE SUBJECT TO BE CHANGED WITHOUT NOTICE.

NOTE 2 : REGARDING MODEL TV-2002 & TV-1402, THE CONSTANT OF THE PART-REFERENCE NO. OF WHICH IS MARKED WITH "*" IS DIFFERENT FROM THAT IN THIS CIRCUIT DIAGRAM, PLEASE REFER TO THE TABLE AT THE UP-RIGHT CORNER.

SCHEMATIC DIAGRAM TV-2102, TV-2002, TV-1402 **aiwa**



S4



NT FROM THAT IN THIS CIRCUIT DIAGRAM, PLEASE REFER TO THE TABLE AT THE UP-RIGHT CORNER